

Federal and California version model year 1977/78


A. General

Information plate

Federal version basic color black

California version basic color yellow

Federal version high altitudes basic color red



Identification of vacuum lines

The basic color of vacuum lines for emission control system is transparent (white).

Additional color stripes are used to facilitate identification of the individual functions.

Lines originating at a vacuum source (suction lines) have only one color stripe.

Lines terminating at a vacuum-operated device (operating lines) have two color stripes. Purple is always the second color.

Emission control system	Color coding of originating vacuum line	Color coding of terminating vacuum line
Ignition		
Advance	red	—
Retard	yellow	—
EGR	brown	brown/purple
Air injection	blue	blue/purple

Recognizing catalyst from color of information plate – basic color/lettering

Model year	Federal version	California version	Federal version high altitudes	Federal version tourist vehicles	California version tourist vehicles
1977	black/silver	green/silver	black/silver	red/silver	blue/silver
1978		black/silver			red/silver

Information plates

This vehicle is provided with catalyst.



1074 – 8259

Tourist vehicle

This vehicle is not provided with catalyst by manufacturer.

Catalyst must be installed prior to import into USA.




1074 – 8260

B. EGR (exhaust gas recirculation)

To reduce nitrogen oxides in exhaust gases, the portion of the gases from the exhaust manifold is returned to the intake pipe by means of a valve.

The quantity of the returned exhaust gas is controlled and in some driving conditions shut off, so that the respective driving characteristics will not be influenced.

Function diagram



EGR components:

EGR valve

The EGR valve is attached to intake pipe and controls the quantity of the recirculated exhaust gases, in dependence of the coolant temperature and the vacuum.




107 - 12830

Therموالve 17 °C (color code blue)

The therموالve is screwed into cylinder head and opens at approx. 17 °C coolant temperature.


Below 17 °C coolant temperature the bimetallic plate is located at the O-ring and closes connection "B".

As from 17 °C coolant temperature the bimetallic plate will snap down under influence of heat. Both connections are connected to each other.



107-10895

The vacuum line to intake pipe should be plugged to connection "B", since this alone will guarantee absolute tightness between bimetallic plate and O-ring.




- 1 Bimetallic plate
- 2 O-ring
- A To vacuum switch
- B To intake pipe

Intake pipe

Inside intake pipe is a pipe with lateral bores (arrows).

These bores distribute the recirculated exhaust gases to the drawn-in fuel-air mixture.



107-10230


EGR is activated:

- Above 17 °C coolant temperature.
- During acceleration.
- During partial load operation.
- During transition to deceleration (coasting).


Operation

Starting at a coolant temperature of approx. 17 °C in cylinder head, during partial load operation and during acceleration, a portion of the exhaust gases is recirculated into the combustion chamber. The addition of exhaust gases to the fuel-air mixture also reduces the generation of nitric oxides. The quantity of the recirculated exhaust gases depends on the throttle valve position (vacuum at throttle valve of carburetor).


A tube with lateral outlet bores vertically located in intake pipe serves to distribute the exhaust gases uniformly to the drawn-in fuel-air mixture.



Depending on throttle valve position, the EGR valve in cylinder head is more or less supplied with exhaust gases via thermovalve 17 °C (61) in cylinder head.



The EGR valve (31) attached to intake pipe opens and permits exhaust gases to flow to intake pipe by way of a duct from exhaust manifold.



C. Air injection

Federal and California version.


To reduce the incompletely burnt components in the exhaust gases, air is injected into hot zone behind exhaust valves or in catalyst.

Afterburning is controlled by way of the engine temperature and vacuum conditions in intake pipe.

To avoid backfiring in exhaust, as well as overheating of catalyst, the air injection is shut off in given driving ranges.

Function diagram


- 1 Carburetor
- 3 Intake pipe
- 40 Air pump
- 41 Air switchover valve
- 42 Check valve
- 61 Thermovalve 17 °C
- 73 Thermovalve 50 °C
- 74 Pressure relief valve
- 76 Catalyst
- 78 Air filter for silencing
- a Air discharge line



Components of air injection:

Air pump (Saginaw pump)


The air pump is an impeller pump with maintenance-free centrifugal filter which cleans the drawn-in air.



Air switchover valve (anti-backfire valve)

The air switchover valve serves the purpose of controlling the air injection in dependence of operating condition of engine.


The housing cover is provided with a vent valve.



107-9139

Pressure relief valve

The excess air delivered by the air pump at high engine speeds is discharged into the atmosphere by the pressure relief valve starting at a line backpressure of approx. 0.3 bar gauge pressure. For silencing, the pressure relief valve is provided with an air filter (muffler).



107-13007

Therموالve 17 °C (color code blue)


The therموالve is screwed into cylinder head and opens at approx. 17 °C coolant temperature. Below 17 °C coolant temperature the bimetallic plate rests against O-ring and closes connection "B".

Above 17 °C coolant temperature, the bimetallic plate snaps downward under influence of heat. Both connections are connected to each other.



107-10895

The vacuum line to intake pipe should be plugged to connection "B", since this alone guarantees perfect sealing between bimetallic plate and O-ring.



- 1 Bimetallic plate
- 2 O-ring

1074-6489/1



Therموالve 50 °C (color code black with green dot, introduced during model year 1978 color code green)

The therموالve (73) is also screwed into cylinder head and **closes** at a coolant temperature of approx. 50 °C.

Below 50 °C coolant temperature the vacuum of primary therموالve 17 °C (61) can act directly on air switchover valve (41) via therموالve 50 °C (73).


Above approx. 50 °C coolant temperature the heated bimetallic plate will snap over and the connection to therموالve 17 °C (61) is closed.

The vacuum hose of therموالve 17 °C (61) should always be plugged to diagonal connection (B), since this alone guarantees perfect sealing with the valve closed.




Air injection lines

a) For air injection into cylinder head a line with four connections, i.e. one for each cylinder, is installed.




b) For air injection into underfloor catalyst an air line is installed underneath vehicle (arrows).



Check valves


The check valves prevent the inflow of hot exhaust gases into air injection lines.



107-9193

Catalyst

The catalyst is designed as an underfloor catalyst and is located in exhaust system in front of mufflers.



107-12962


Operation

The air pump driven by the crankshaft and a V-belt delivers continuously air when the engine is running.


The air flows to pressure relief valve (74), which discharges the excess air delivered at high engine speeds into the atmosphere at a backpressure of approx. 0.3 bar.

The pressure relief valve (74) delivers the air through air switchover valve (41) either into the injection ducts in cylinder head or into catalyst.

The air switchover is controlled by the air switchover valve via thermostatic valve 17 °C (61) and 50 °C (73).



107-13184




107-12897

There are three temperature ranges:

1. Coolant temperature below 17 °C
(Air injection into catalyst)

Therموالve 17 °C (61) is closed, therموالve 50 °C (73) is open. No vacuum flows to diaphragm of air switchover valve (41), the diaphragm is connected to atmosphere by the vent cap on valve. The compression spring in air switchover valve closes the injection line to cylinder head. The delivered air is blown into catalyst. This will prevent overheating of catalyst in warming-up phase.




2. Coolant temperature above 17 °C and below 50 °C
(Air injection into cylinder head)

Therموالve 17 °C (61) and therموالve 50 °C (73) are open. The vacuum from intake pipe arrives at diaphragm of air switchover valve (41) and the diaphragm is pushed in upward direction against the spring force. The injection line to cylinder head is opened, the line to catalyst is closed. The air is blown into exhaust ducts of cylinder head via check valve (42).


3. Coolant temperature above 50 °C
(Air injection into catalyst)

Therموالve 17 °C (61) is open, therموالve 50 °C (73) is closed. No more vacuum arrives at diaphragm of air switchover valve. The diaphragm chamber is connected to atmosphere via vent cap on valve.




The compression spring in air switchover valve closes the injection line to cylinder head. The supplied air is injected into catalyst via check valve (42).

The oxygen in the injected air mixes with the hot exhaust gases and reacts in catalyst.



D. Catalyst


The catalyst is designed as an underflorr catalyst and is located in exhaust system in front of mufflers.



The catalyst is designed as a double bed catalyst, i.e. the housing contains two monoliths, a slim one in front and a wide one behind.

The monoliths (3) are oval, honeycomb-shaped bodies of ceramic material, which are elastically mounted in wire netting (2) inside catalyst housing. The noble metal evaporated on the monoliths, the actual catalyst, accelerates the oxidation of CO and hydrocarbons at the respective temperature with the addition of fresh air.

The air is injected into catalyst behind the small monolith above annular duct (4).

- 
- 1 Distribution plate
 - 2 Wire netting
 - 3 Monoliths
 - 4 Annular duct

107-12963

To keep catalyst in operating condition, run engine with unleaded fuel only.

Preventing overheating of catalyst

Extended overheating of catalyst will lead to catalyst damage, i.e. the monoliths in catalyst may melt.

The catalyst may overheat, if:

- a) The specified engine service is not maintained.

Perfect spark plugs are important for life of catalyst.

- b) Irregular operation of engine results in excessive enrichment of fuel-air mixture.
- c) The emission control system is arbitrarily changed.

E. Air injection tourist vehicles

Federal and California version model year 1977/78


Tourist vehicles are supplied ex factory without a catalyst.

To reduce the incompletely burnt components in exhaust gas, air is injected into hot zone behind exhaust valves.

Afterburning is controlled via the engine temperature and vacuum conditions in intake pipe.

To prevent backfiring in exhaust, the air injection is shut off in given driving ranges.

Function diagram



Components of air injection system:

Except for catalyst, components are similar to Federal and California version.

Operation

The air pump driven by crankshaft by means of a V-belt delivers continuously air while the engine is running.

The air flows to pressure relief valve (74), which discharges excessive air delivered during high engine speeds into the atmosphere at a back-pressure of approx. 0.3 bar.


The pressure relief valve (74) guides the air by way of air switchover valve (41) either into the injection ducts in cylinder head or into the open air (atmosphere).

The air switchover procedure is controlled by the air switchover valve via thermostats 17 °C (61) and 50 °C (73).

There are three temperature ranges:


1. Coolant temperature below 17 °C (Air injection into the open air)

Thermostat 17 °C (61) is closed, thermostat 50 °C (73) is open. No vacuum flows to diaphragm of air switchover valve (41), the diaphragm is connected to atmosphere by the vent cap on valve. The compression spring in air switchover valve closes the injection line to cylinder head. The delivered air is blown into the open air.



2. Coolant temperature above 17 °C and below 50 °C (Air injection into cylinder head)

Thermostat 17 °C (61) and thermostat 50 °C (73) are open. The vacuum from intake pipe arrives at diaphragm of air switchover valve (41) and the diaphragm is pushed in upward direction against the spring force. The injection line to cylinder head is opened and the line into the open air is closed. The air is blown into exhaust ducts of cylinder head via check valve (42).



3. Coolant temperature above 50 °C (Air injection into the open air)


Thermostat 17 °C (61) is open, thermostat 50 °C (73) is closed. No more vacuum arrives at diaphragm of air switchover valve. The diaphragm chamber is connected to atmosphere via vent cap on valve. The compression spring in air switchover valve closes the injection line to cylinder head. The delivered air is blown into the atmosphere by way of the air discharge line.

F. Fuel evaporation control system model year 1977

A fuel evaporation control system has been installed to improve emissions which are not directly connected with engine combustion.

Function diagram

- 1 Carburetor with positive vent valve
- 2 Valve system
- 3 Fuel tank
- 39 Charcoal canister




Components of fuel evaporation control system:

Valve system

The valve system is mounted underneath vehicle at level of rear legroom.

The valve system comprises three valves:


- 1. Negative vent valve
- 2. Pressure relief valve
- 3. Positive vent valve



The **negative vent valve** opens at a slight overpressure. The evaporation vapors are flowing via negative vent valve (1, direction B) into a line toward charcoal canister.

The **pressure relief valve** opens as a safety valve in the event of an overpressure in fuel evaporation control system. The fuel vapors are bled directly into the open air.


The **positive vent valve** opens whenever cooling down of fuel tank results in a vacuum.



- 1 Negative vent valve
- 2 Pressure relief valve
- 3 Positive vent valve
- A To valve/to expansion tank
- B To charcoal canister
- C Fresh air input
- D Output pressure relief valve

Charcoal canister

The fuel evaporation vapors from fuel tank, as well as those from float chamber, are stored in charcoal canister and are drawn again out of canister when driving.




- A Connection tank vent
- B Draw-off connection
- C Connection float chamber vent valve


Float chamber vent valve

The carburetor is provided with an electromagnetic float chamber vent valve. The valve is actuated when the ignition is switched on or off.

When the ignition is switched off, the solenoid of the valve is de-energized. Compression spring (3) presses the valve plate (4) against upper valve seat (5). The float chamber evaporation vapors are now flowing from bore B over valve seat through connection C to charcoal canister (external venting).




With the ignition switched on, the valve is energized. The solenoid (7) moves down and pushes the valve rod (1) in downward direction. Valve plate (4) closes connection C. The carburetor is switched to internal venting. The float chamber is now vented through bore A via valve through bore B.




Draw-off connection on carburetor

To draw fuel evaporation vapors from charcoal canister the carburetor is provided with a draw-off connection (118), which is provided with a vacuum in dependence of the throttle valve position.



Operation

The fuel evaporation vapors from fuel tank are routed to charcoal canister (39) via valve system (2). The fuel evaporation vapors from the float chamber are also routed into charcoal canister via the float chamber vent valve with the engine stopped and the ignition switched off and are stored there. From charcoal canister (39) the fuel evaporation vapors are drawn-off via the draw-off connection (B) with the engine running and in dependence of the throttle valve position in carburetor.




107-13167

- A Connection tank vent
- B Draw-off connection
- C Connection float chamber vent valve

G. Fuel evaporation control system model year 1978

A fuel evaporation control system has been installed to improve emissions which are not directly connected with engine combustion.




- 1 Carburetor with positive vent valve
- 3 Fuel tank
- 4 Vent valve unit
- 5 Regenerating valve
- 39 Charcoal canister

1474-7352/3

Vent valve unit


The vent valve unit is mounted underneath vehicle at level of rear legroom and takes the place of the valve system known from model year 1977.

The valve unit comprises a negative vent valve (pressure relief valve) and a positive vent valve (vacuum relief valve).



Charcoal canister

The fuel evaporation vapors from fuel tank, as well as those from float chamber, are stored in charcoal canister and are drawn off again while driving.




- A Connection tank vent
- B Draw-off connection
- C Connection float chamber positive vent valve

107-9131

Regenerating valve


The regenerating valve (5) is located in regenerating line from charcoal canister to carburetor.




Float chamber positive vent valve

The carburetor is provided with an electromagnetic float chamber positive vent valve. The valve is actuated by switching the ignition on or off.

With the ignition switched off, the solenoid of the valve is de-energized. Compression spring (3) presses the valve plate (4) against upper valve seat (5). The float chamber evaporation vapors are now flowing from bore B over valve seat through connection C to charcoal canister (external venting).




With the ignition switched on, the valve is energized. The solenoid (7) moves down and pushes the valve rod (1) in downward direction. Valve plate (4) closes connection C. The carburetor is switched to internal venting. The float chamber is now vented through bore A via valve through bore B.



Draw-off connection on carburetor

To draw fuel evaporation vapors from charcoal canister the carburetor is provided with a draw-off connection (118), which is provided with a vacuum in dependence of the throttle valve position.



Fuel tank cap

To avoid increased overpressure in fuel tank, the fuel tank cap has been modified.

Operation



Evaporation system

The vent valve unit (4) increases the pressure in fuel tank to 30–50 mbar. As a result, fewer fuel evaporation vapors will be able to escape from fuel tank.

When the pressure in fuel tank is at 30–50 mbar, the vent valve unit (4) opens and permits the fuel evaporation vapors to flow to charcoal canister, where they are stored when the engine is stopped.


Vent valve unit open to charcoal canister

- | | |
|-----------------------|--------------------------------|
| 1 Compression spring | 6 Positive vent valve |
| 2 Valve housing | 7 Connection |
| 3 Spring retainer | A Connection charcoal canister |
| 4 Negative vent valve | B Connection fuel tank |
| 5 Valve plate | |



When the fuel cools down, the intake of air or fuel evaporation vapors from charcoal canister via positive vent valve (6) will compensate a vacuum of 1–16 mbar. If the vacuum in fuel tank drops below 1 mbar, the positive vent valve (6) will close.

If the pressure in the fuel tank increases above 0.1–0.3 bar due to a malfunction in the fuel evaporation system, the fuel vapors escape via the fuel tank cap.



Vent valve unit open to fuel tank

The fuel evaporation vapors from float chamber are routed to and stored in charcoal canister with the engine stopped and the ignition switched off via float chamber positive vent valve.


Regenerating system

The charcoal canister is connected to the carburetor by means of a line in which the regenerating valve (5) is enclosed.

When the engine is running and the vacuum in the regenerating line exceeds 30–50 mbar, the regenerating valve opens. The fuel vapors stored in charcoal canister can be drawn off depending on throttle valve position of carburetor.


Regenerating valve (open)

- | | |
|-----------------------|-------------------------------------|
| 1 Compression spring | 5 Valve plate |
| 2 Valve housing | 6 Connection |
| 3 Spring seat | A Connection throttle valve housing |
| 4 Negative vent valve | B Connection charcoal canister |



When the throttle valve opens, the two regenerating bores in carburetor, which are entering a common duct, are both passed over one after the other. As a result, regeneration in lower partial load range begins in dosages which are not influencing the driving characteristics.

At idle and during deceleration (throttle valve closed) the two regenerating bores are at atmospheric side of throttle valve. There is no regeneration of charcoal in canister.



Regenerating valve (closed)


H. Vehicles for Federal version high altitudes model year 1977

Vehicles for Federal version high altitudes are identical with Federal version. But for extended driving in high altitudes the altitude correction requires adjustment and the idle speed emission value in the higher **altitude** must be checked or readjusted, if required.

Altitude correction

The carburetor is set to sea level and for this reason supplies too rich a fuel-air mixture at higher altitudes, a consequence of low air pressure.

158 Hand wheel
159 Stop



Operation

By turning hand wheel (158) clockwise the fuel nozzle is displaced in upward direction. As a result, the fuel-air mixture will become leaner throughout entire speed or load range.

The circumference of the hand wheel (158) shows two altitude marks with stops.

NORMAL = up to approx. 1,200 m (4,000 ft)
4,000 ft = above approx. 1,200 m (4,000 ft)

Up to an altitude of approx. 1,200 m (4,000 ft) the hand wheel should be set to the **normal** mark.

During predominant or constant operation at altitudes above approx. 1,200 m (4,000 ft) turn hand wheel clockwise to 4,000 ft mark.

Then check idle speed emission value and idle speed in respective **altitude** and adjust, if required.

If the vehicles are again operated for extended periods in low altitude or at sea level, turn hand wheel back to normal, also check idle speed and idle speed emission value and readjust, if required.

